- Understand the potential of suspension airbags to cause harm - For underside 'suspension airbag inspections', a face shield and hearing protection must be worn at all times, until the inspection in complete. - When general maintenance is being undertaken on the underside of the trailer, the air must be fully released from the suspension system - Eliminate/Reduce the risk where practicable, removal of air, pressure, stored energy - always follow the correct procedures - Treat any pressurised or closed pressurised system with care and if in any doubt as to the systems integrity, stop and report this to supervisors/managers immediately

---

LOCATION:	**CONTRACTING - ON-HIGHWAY**	**ALERT STATUS:**	**Normal**
ACTIVITY:	**MAINTENANCE & HOUSEKEEPING**	**DATE ISSUED:**	**14/06/2019 09:40:40**
SUB ACTIVITY:	**N/A**	**INCIDENT No:**	**01515**